

LMU 3000 with Y cable. Quick installation guide



Note: If possible, move the modem to the highest point under the dash close to the window. Don't forget to put tie wraps on cables under the dash. Be sure there are no metal obstructions. Plastic material doesn't interfere with cellular and GPS signals. Antennas are built-in for easy installation

If you need additional information, don't hesitate to contact Technical Support at support@fleetfreedom.com, 1 (866) 787-2548 opt 2

Fleet Freedom
4020 rue St-Ambroise, suite 495 Montréal, Québec H4C 2C7 – 1 (514) 604-4066
www.fleetfreedom.com

