



## GEN X OBDII - Installation Guide



The Male Connector must be inserted into the main vehicle connector you will find under the dash



### Install Verification:

Green LED should be flashing rapidly when ignition is on and slowly when ignition is off

**FLEET FREEDOM®**

630 The East Mall, Etobicoke ON M9B 4B1 -

[www.fleetfreedom.com](http://www.fleetfreedom.com)

Fleet Freedom Support Phone Number: 1 (866) 787-2548 Option 2 English or 9 French

Email: [support@fleetfreedom.com](mailto:support@fleetfreedom.com)



**Note:** If possible, move the modem to the highest point under the dash close to the window and secure in place with tie wraps. Don't forget to put tie wraps on cables under the dash. Be sure there are no metal obstructions. Plastic material doesn't interfere with cellular and GPS signals. Antennas are built-in for easy installation.

If you need assistance with your Account, please contact one of our Customer Service Representatives.

Office Hours: Monday to Friday 9:00 AM - 5:00 PM EST

Fleet Freedom Support Phone Number: 1 (866) 787-2548 Option 2 English or 9 French

Email: [support@fleetfreedom.com](mailto:support@fleetfreedom.com)



630 The East Mall, Etobicoke ON M9B 4B1 -

[www.fleetfreedom.com](http://www.fleetfreedom.com)

Fleet Freedom Support Phone Number: 1 (866) 787-2548 Option 2 English or 9 French

Email: [support@fleetfreedom.com](mailto:support@fleetfreedom.com)