




Temperature Sensor Installation with GenX modems

- 1) Connect the Blue wire of the temperature sensor to the Black wire of I/O Harness
- 2) Connect the Yellow wire from the temperature sensor to the Grey Wire of the I/O Harness
- 3) Red wire of the temperature sensor can be left floating



If you need assistance with your Account, please contact one of our Customer Service Representatives.

Office Hours: Monday to Friday 9:00 AM - 5:00 PM EST

Fleet Freedom Support Phone Number: 1 (866) 787-2548 Option 2 English or 9 French

Email: support@fleetfreedom.com

FLEET FREEDOM®

630 The East Mall, Etobicoke ON M9B 4B1 -

www.fleetfreedom.com

Fleet Freedom Support Phone Number: 1 (866) 787-2548 Option 2 English or 9 French

Email: support@fleetfreedom.com